

Hanging Guidelines

These guidelines are to be read in conjunction with specific pasting instructions for our paper options and paste (if purchased).

If you have followed our "how to measure your wall" instructions correctly, your Wall Mural is produced as standard 5cm bigger than your wall on all sides.

1, Your Wall Mural paper drops are 50cm wide, so mark the left hand side of your wall 45cm from the left and mark a vertical line with a level.

2, Follow pasting instructions specific to your chosen wallpaper / adhesive and align the right side of the first drop to your vertical line marked in step 1.

3, Once in position and brushed flat to the wall trim off your excess 5cm from the top, bottom and left of this drop with a sharp knife.

4, Hang the second drop and align the pattern trying not to overwork or stretch your mural.

5, Trim off the excess top and bottom.

6, Repeat this process until all drops are installed.

